


REFILL INSTRUCTIONS FOR THE R2

To fill your Ceramic Heating Disc Chamber, follow these simple steps:

- Unscrew Ceramic Heating Disc Chamber at Top. (Chamber Connector / Mouthpiece)
- Fill the Ceramic Heating Disc Chamber with your herbs or Waxy oil.
- Then Refit Top. (Chamber Connector / Mouthpiece)
- Press the power button... wait 2-3 seconds then start to inhale slowly.



Do not pack the heating cartridge too tightly with your waxy oil.